


Quick Start Guide

nomono stellar kit

English2

French22


What's in the Box:



2 x Nomono
Stellar Mics



Charging Dock



Travel Sleeve



Reset Pin

Getting Started

Step 1: Charge Your Mics

Plug in the Charging Dock and place the Nomono Stellar Mics inside to begin charging.

The mics need to be charged before first use.

Step 2: Download the App

Download the Nomono Studio app from the App Store (iOS) or Google Play (Android).

Use the QR code to download the app.



Sign in or create a Nomono account to get started.

Step 3: Pair the Mics

In the Nomono Studio app, select Stellar Kit from the options and follow the instruction in the app to set up your kit.

Make sure the mics are charged, undocked, and active (LED should be pulsing).

Hold the mics close to your phone, and once the mics show up on the screen, select the mic to connect.

Step 4: Record

You're ready to start the recording.

How to use your Stellar Mics

Powering On/Off

The microphones stay on for 10 minutes after being removed from the charging dock. After that, they enter sleep mode to prolong battery time.

To wake a microphone, simply double-tap its front face.

When on, the LED will be lit; when off, the LED will be off.

Optimal Recording Placement

Place the mic at the center of your chest, clear of clothing or hair for best sound quality.

Critical Stellar Mic LED States

-  **Orange blinking LED**
Critically low battery
-  **Blinking mic color LED while recording**
Critically low battery or out of storage
-  **LED off**
Out of battery or Stellar Mic in sleep mode (double tap, dock or reset to wake)

For help or more information about your Stellar Kit, visit our knowledge base or contact our support on support.nomono.co.

Notice

© 2023 Nomono AS. All rights reserved.

Use of the Nomono wordmark and logos for commercial purposes without the prior written consent of Nomono may constitute trademark infringement and unfair competition. Nomono wordmark, device mark and app icon are registered trademarks in Norway and other countries and regions. Other products and company names mentioned herein may be trademarks of the respective companies. No licence, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Nomono or others. Nomono disclaims any and all liability for any losses or damages incurred by you or third parties arising from alteration, modification, copying or reverse engineering. Every effort has

been made to ensure that the information in this manual is accurate. Nomono is not responsible for printing or clerical errors.

Warranty

This Limited Warranty applies to the Nomono Stellar Kit and included accessories, and only for these products, purchased from Nomono AS. This Limited Warranty covers any defects in material or workmanship under normal use during the Warranty Period. During the Warranty Period, Nomono will repair or replace, at no charge, products or parts of a product that proves defective under normal use and maintenance. The Warranty Period for the Stellar Kit, purchased from Nomono, is 1 year from the date of shipment. This Limited Warranty does not cover any problem that is caused by: conditions, malfunctions or damage not resulting from

normal use of the product, such as those outlined in the safety information section of this document. For additional information, please see “TERMS FOR THE PURCHASE OF PRODUCTS”.

If this product was purchased from a reseller or distributor, please contact them directly for questions regarding the warranty.

Safety

Please read the following carefully before using the Nomono Stellar Kit.

Magnets

-Charging Dock, Stellar Mic and the clip magnets contain strong magnets:

- Keep the Clip Magnets away from children. Swallowing magnets can cause serious harm.
- Keep Stellar Mics at a safe distance and do not attach

them using the clip magnets if you use a pacemaker or a similar device.

- Keep hard drives, credit cards and RFID devices away from the aforementioned products.

Batteries

- The Stellar Mic is powered with Lithium batteries:
- In case of fire, extinguish using a fire blanket, dry powder fire extinguisher or sand.
- Do not disassemble or open these products, this will lead to a loss of warranty, and risk of fire if a battery is pierced.
- Before taking aboard an aircraft, familiarise yourself with the airline's guidelines for products with batteries.
- Should you notice that the product swells, or leaks battery fluids, discontinue its use, and contact Nomono AS.

Water / Liquids

- Do not submerge the products in liquid.
- Do not use chemicals to clean the products.
- Do not plug in the Nomono Charging Dock if it is wet.
- Do not use liquid/wet surfaces to wash the spring-loaded connectors while the dock is connected to power.

Electrical safety

- Only use standard 5V-adapters
- Stellar Mic operating temperature: -10 °C to +45 °C
- Stellar Mic charging temperature: 0°C to 45°C.
- Stellar Mics charge automatically when docked in a powered charger but will automatically stop charging in temperatures outside of the stated charging temperature.

- Do not store or charge the products near heat sources, in pressurised

containers, or in a microwave oven.

- Do not exceed stated operating or charging temperatures for operation or charging respectively.

- Do not store in temperatures exceeding the charging temperature (e.g. storing in a car on a hot day, or in a freezer).

- Do not leave the Stellar Mics fully discharged over long periods, as this might permanently reduce battery life. It is recommended to charge the batteries at least once every 6 months to ensure battery longevity

North America

USA

FCC Notice

This device complies with Part

15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause interference, and

(2) this device must accept any interference, including interference that may cause undesired operation of the device.

Wireless notice

This device complies with FCC radiation exposure limits set forth for an uncontrolled environment and meets the FCC radio frequency (RF) Exposure Guidelines. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against

harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

1. Reorient or relocate the receiving antenna.
2. Increase the separation between the equipment and receiver.
3. Connect the equipment into an outlet on a circuit different

from that
to which the receiver is connected.

4. Consult the dealer or an experienced radio/TV technician for help.

Canada

IC notice

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

(1) This device may not cause interference. (2) This device must accept any interference, including interference that may cause undesired operation of the device. Do not tamper with the electronics in the product in general, or radio components therein, as this might cause it to emit harmful interference, and lose

your authority to operate this device.

Stellar Mics:

Frequency range 2.4 GHz:
2402-2480 MHz, Power 2.4
GHz: < 3 dBm

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

(1) L'appareil ne doit pas produire de brouillage; (2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

This equipment complies with ISSED radiation exposure limits set forth for an uncontrolled

environment. End user must follow the specific operating instructions for satisfying RF exposure compliance. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. The portable device is designed to meet the requirements for exposure to radio waves established by the ISED.

Cet équipement est conforme aux limites d'exposition aux rayonnements ISED établies pour un environnement non contrôlé. L'utilisateur final doit suivre les instructions spécifiques pour satisfaire les normes. Cet émetteur ne doit pas être co-implanté ou fonctionner en conjonction avec toute autre antenne ou transmetteur. Le dispositif portatif est conçu pour répondre aux exigences d'exposition aux ondes radio établie par le développement énergétique DURABLE.

EU / UK

Nomono AS declares that the Nomono Micro is in compliance with the relevant EU directives and standards. A copy of our declaration of conformity is available at request <https://knowledge.nomono.co/declaration-of-conformity>

Nomono AS declares that the Nomono Stellar Mic is in compliance with the relevant EU directives and standards. A copy of our declaration of conformity is available at request <https://knowledge.nomono.co/declaration-of-conformity>

Stellar Mics:

Freq. range 2.4 GHz: 2402-2480 MHz, Power 2.4 GHz: < 3 dBm

SAR

This product has very low levels of RF energy, so it is deemed to comply without testing of specific absorp-

tion rate (SAR). This equipment complies with Radiation Exposure limits set forth for an uncontrolled environment.

Waste Electrical & Electronic Equipment

This marking on our products, packaging, accessories etc.



indicates that the product(s) and any electronic accessories

(USB cable etc.) should not be disposed of with residual household waste. To prevent harm to the environment, human and animal health from uncontrolled waste disposal, please follow local laws or guidelines regarding correct disposal and recycling to promote sustainable use of electrical and electronic equipment. Please contact the retailer, or the local government office for details on where and

how to properly recycle these items. This product is RoHS and REACH compliant.

Power

5 V, 400 mA DC

Product markings

US

Stellar Mic: FCC ID: 2A9CX-MIC1 (Visible on label, and through phone app)

CA

Stellar Mic / Model No. 7090055400101 / IC: 29748-MIC1

EU



UK




AU / NZ




Guide de démarrage rapide

nomono stellar kit


Contenu de la boîte:




2 x Nomono
Stellar Mics



Charging Dock



Pochette de transport



Épingle de
réinitialisation

Premiers pas

Étape 1 : Chargez vos micros

Branchez le Charging Dock et placez les Nomono Stellar Mics à l'intérieur pour commencer de charger.

Les micros doivent être entièrement chargés avant la première utilisation.

Étape 2 : Téléchargez l'application

Téléchargez l'application Nomono Studio depuis l'App Store (iOS) ou le Google Play (Android).

Scannez le QR pour télécharger l'appli.



Connectez-vous ou créez un compte Nomono pour commencer.

Étape 3 : Associez les micros

Depuis l'application Nomono Studio, sélectionnez Stellar Kit parmi les options et suivez les instructions pour configurer votre kit.

Assurez-vous que les micros soient chargés, sortis du dock et actifs (la LED doit pulser).

Tenez les micros près de votre téléphone, puis sélectionnez-les à l'écran lorsqu'ils apparaissent pour les connecter.

Étape 4 : Enregistrez

Vous pouvez maintenant commencer l'enregistrement.

Comment utiliser vos Stellar Mics

Allumer / Éteindre

Les microphones restent allumés pendant 10 minutes après avoir été retirés du Charging Dock.

Passé ce délai, ils passent automatiquement en mode veille pour économiser leur batterie.

Pour rallumer un micro, il suffit de tapoter deux fois sur sa face avant.

Lorsque le micro est allumé, la LED est allumée. Lorsqu'il est éteint, la LED est éteinte.

Placement optimal pour l'enregistrement

Placez le micro au centre de votre poitrine, sans le couvrir de vêtements ou de cheveux, pour un son optimal.

États critiques de la LED du Stellar Mic



LED orange clignotante

Batterie presque vide



LED de couleur clignotante pendant l'enregistrement

Batterie presque vide ou stockage plein



LED éteinte

Batterie vide ou Stellar Mic en veille (tapoter, remettre dans le dock ou réinitialiser pour le rallumer)

Pour plus d'aide ou d'informations sur votre Stellar Kit, consultez notre base de connaissances ou contactez notre service client sur support.nomono.co.

Notice légale

© 2023 Nomono AS. Tous droits réservés.

L'utilisation de la marque verbale Nomono et de ses logos à des fins commerciales sans l'autorisation écrite préalable de Nomono peut constituer une violation de marque déposée et une concurrence déloyale.

La marque verbale Nomono, son symbole graphique et l'icône de l'application sont des marques déposées en Norvège et dans d'autres pays ou régions.

Les autres produits ou noms de sociétés mentionnés peuvent être des marques déposées par leurs propriétaires respectifs.

Aucune licence, expresse ou implicite, n'est accordée par les présentes au titre de brevets, droits d'auteur ou autres

droits de propriété intellectuelle appartenant à Nomono ou à des tiers.

Nomono décline toute responsabilité en cas de perte ou de dommage subis par vous ou par des tiers résultant d'une altération, modification, copie ou rétro-ingénierie.

Tous les efforts ont été faits pour garantir l'exactitude des informations contenues dans ce guide. Nomono ne saurait être tenu responsable des erreurs d'impression ou de frappe.

Sécurité

Veuillez lire attentivement les informations suivantes avant d'utiliser le Nomono Stellar Kit.

Aimants

Le Charging Dock, les Stellar Mics et les clips contiennent de aimants puissants :

- Gardez les clips aimantés hors de portée des enfants. Avaler un aimant peut entraîner de graves complications.

- Ne portez pas les Stellar Mics avec les clips aimantés si vous utilisez un pacemaker ou un dispositif médical similaire.

- Tenez les disques durs, cartes bancaires et dispositifs RFID éloignés de ces produits.

Batteries

Les Stellar Mics sont équipés de batteries au lithium :

- En cas d'incendie, utilisez une couverture anti-feu, un extincteur à poudre sèche ou du sable.

- Ne démontez pas et n'ouvrez pas ces produits — cela annule la garantie et peut provoquer un incendie si une batterie est perforée.

- Avant de monter à bord d'un avion, informez-vous des règles de votre compagnie aérienne concernant les produits contenant des batteries au lithium.

- Si vous constatez un gonflement ou une fuite, cessez immédiatement l'utilisation et contactez Nomono AS.

Eau / Liquides

Ne plonge jamais les produits dans un liquide.

- N'utilisez pas de produits chimiques pour les nettoyer.

- Ne branchez pas le Charging Dock s'il est mouillé.

- Ne nettoyez pas les connecteurs à ressort avec un chiffon mouillé ou sur une surface humide lorsque le dock est alimenté.

Sécurité électrique

- Utilisez uniquement des adaptateurs standards 5V.

- Température de fonctionnement des Stellar Mics : de -10 °C à +45 °C

- Température de charge : de 0 °C à 45 °C

- Les Stellar Mics se rechargent automatiquement lorsqu'ils sont placés dans un dock alimenté, mais cessent de se charger si la température sort de cette plage.


- Ne stockez pas et ne chargez pas les produits à proximité de sources de chaleur, dans des contenants pressurisés ou dans un micro-ondes.

- Ne dépassez pas les températures de fonctionnement ou de charge recommandées.

- Ne stockez pas les produits à des températures supérieures à la température de charge (par exemple dans une voiture en été ou un congélateur).

- Ne laissez pas les Stellar Mics entièrement déchargés

sur de longues périodes, car cela peut réduire la durée de vie des batteries. Il est recommandé de les recharger au moins tous les 6 mois pour préserver leur performance.



Version 1.1